## FROGWEAR® SAFETY WEAR



## **Safety Vest Sizing Chart**

Choosing the correct size in safety apparel is crucial for optimal protection and performance.

For an accurate size and fit in Global Glove safety vests, please refer to the following general sizing dimensions.



Body Length

SIZE	BODY LENGTH	ACROSS CHEST	SLEEVE LENGTH (CLASS 3 VESTS ONLY)
XS	26.5	23.25	11.5
SMALL	26	24.75	11.75
MEDIUM	26	25	12.25
LARGE	27.25	26.5	12.5
XL	27.5	28	13
2XL	28	30	13.5
3XL	28.75	30.75	13.75
4XL	29.5	31.5	14.25
5XL	30.25	32.25	14.5
6XL	31.5	33.25	15
7XL	31.5	34.25	15.25

SIZE	BODY LENGTH	ACROSS CHEST	SLEEVE LENGTH (CLASS 3 VESTS ONLY)
S/M	26	25.25	12.25
L/XL	28	28	13
2XL/3XL	28.75	30.75	13.75
4XL/5XL	30.25	32.25	14.5
6XL/7XL	31.5	33	15.25

## ALL MEASUREMENTS IN INCHES

Estimate size to the closest fit. Body proportions may vary.



